
SPRACHT

Voice Center[™] External Microphone

Voice Center Conference Phones have built-in microphones for complete 360° coverage in areas up to 10 x 15 ft (3 x 4.5 m).



Voice Center Conference Phones also have RJ-22 input jacks for two external microphones to allow for irregular layouts and to extend coverage for larger areas, as illustrated below.



The Voice Center EM-101 External Microphone (sold separately from the conference phone) comes with a 70-inch (1.8 m) cable with RJ-22 connector. The EM-101 External Microphone works with most conference phones equipped with RJ-22 microphone jacks.

Installation of External Microphone

 Plug the RJ-22 microphone connector into a microphone connector on your conference phone. On Voice Center Conference Phones, the two microphone connectors are labeled "EXTERNAL MIC." On the Model 2012, they are located on the sides of the unit; on the Model 2010, the connectors are located on the underside of the unit.



Model 2010



2. Place the external microphone at least 18 inches (0.5 m) from the Conference Phone and any other external microphone. The diagrams above illustrate some common arrangements for external microphones with a conference phone.

Specifications

Microphone sensitivity	-47 ±4 db	
Connection	70 in. (1.8 m) cable	RJ-22 connector
Weight	2.4 ± 0.2 oz. (69 ± 5 g)	

Limited Warranty Policy

Spracht warrants its products against defects in material and workmanship under normal use and service for one year from the original date of purchase. Spracht, at its option, shall repair or replace a defective unit covered by this warranty.

In order to keep this warranty in effect, the product must be handled and used as prescribed in the instructions accompanying the product. This warranty does not cover any damage due to accident, misuse, abuse, or negligence. Repair or replacement, as provided under this warranty, is the exclusive remedy. Spracht shall not be liable for any incidental or consequential damages. Implied warranties of merchantability and fitness for a particular purpose on this product are limited in duration to the duration of this warranty.